




How to remove a 3D print




1. Grab a **spatula** located at the **gray tables** in a **yellow box**.




2. Locate your 3D printer with your 3D print.




3. Place your **spatula** underneath a **corner** on your print.



4. Gently leverage the spatula up.



5. As you are leveraging the print up, **move the spatula underneath it**.



6. This will cause the print to “pop off” the build plate.

